

Quick Setup Guide

DC190L-X

1 Ventilation

Your fridge needs plenty of air flow in and out of the compressor area. (Refer owner's manual pages 7)

2 Wire Direct

Wire your fridge directly to your battery terminals on a dedicated circuit only. (Refer owner's manual page 2)

3 Door Alignment

If the door has been removed, or hinges are swapped from right to left, check the door alignment, and ensure the rubber door seals are making 100% contact. (Refer owner's manual pages 4)

4 Thermostat

Use the lowest number possible. Start on 3 and wait 24 hours. Adjust upwards 1 notch if your drinks are not cold. Between 3 – 5 is the best setting. Do not go above 6. (Refer owner's manual page 3)

5 Packing

Arrange items in the fridge so there is space for the cold air to circulate, especially on the top shelf. Avoid using solid plastic tubs or foam packages as they block air movement. (Refer owner's manual page 5.5)

That's it, enjoy!



Need a hand? Contact us direct.

T 03 8080 9990 **E** info@bushman.com.au

Mon-Fri 8:30am to 4:30pm